


Smartphones you can use as your lockbox key

Add Supra eKEY® software to any smartphone listed below and turn it into your lockbox key. Devices not on this list are not supported for use with eKEY software.



Android™

Ally	Eris
Captivate	Evo
Droid	Hero
Droid 2	Incredible
Droid X	Nexus One



Androids require the use of the eKEY Fob to access the iBox



BlackBerry®

8800 series (8820, 8830, 8830 World Edition)
All models in the following product lines:
Bold Storm
Curve Torch
Pearl/Pearl Flip Tour



BlackBerrys require the use of the eKEY Fob to access the iBox



iPhone

iPhone (original)	iPhone 3GS
iPhone 3G	iPhone 4



iPhones require the use of an eKEY Adapter to access the iBox



Windows Mobile®

Infrared Models

8125
8525
HTC Mogul
HTC P4300
iPAQ 6900 Series
MDA
PPC-6700/6800
Treo 700w/wx
Treo 750
Treo 800w
Treo Pro (850)
XV 6700/6800

Non-Infrared Models*

AT&T Blackjack II
AT&T Fuze
AT&T Fuze NC
HTC Fuze
HTC Imagio
HTC Ozone
HTC Pure
HTC Shadow
HTC Tilt 1 & 2
HTC Touch Diamond
HTC Touch Pro 1 & 2
HTC Wing

iPAQ 900
LG Insite
MOTO Q™ 9c
Pantec Duo
Samsung Ace
Samsung Epix
Samsung Intrepid
Samsung Omnia 1 & 2
Samsung Saga
PN-820
XV 6900

The Non-Infrared Windows Mobile devices may be used but have not been fully tested.



**Non-infrared Windows Mobile devices require the use of the eKEY Fob to access the iBox*

Palm®

Centro	Treo 650	Treo 700p
Treo 600	Treo 680	Treo 755p



www.supraekey.com

© 2010 UTC Fire & Security. All rights reserved. Android is a trademark of Google Inc. BlackBerry is a registered trademark of Research in Motion (RIM). iPhone is a registered trademark of Apple, Inc. Palm is a registered trademark of Palm, Inc. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. All other brand and product names are or may be trademarks of, and are used to identify products or services of, their respective owners.